BATSTAR
FOR YOUR CORDLESS WORLD

Easy Repair Instruction

for the Overhead Comfort-Headset

BATSTAR
FOR YOUR CORDLESS WORLD

Easy Repair Instruction

for the Overhead Comfort-Headset

BATSTAR
FOR YOUR CORDLESS WORLD



Put the headset in front of you

BATSTAR
FOR YOUR CORDLESS WORLD



Get grip of the mounting disk through the ear-pad

BATSTAR
FOR YOUR CORDLESS WORLD



Slightly push…

BATSTAR
FOR YOUR CORDLESS WORLD



…and rotate…

BATSTAR
FOR YOUR CORDLESS WORLD



…to take off the mounting disk inclusive the ear-pad

BATSTAR
FOR YOUR CORDLESS WORLD



For the next step you will need a screwdriver



With the help of the screwdriver…





…slightly push four clips to the outside

BATSTAR
FOR YOUR CORDLESS WORLD



Carefully…

BATSTAR
FOR YOUR CORDLESS WORLD



…push down the speaker

BATSTAR
FOR YOUR CORDLESS WORLD



Turn around the speaker

BATSTAR
FOR YOUR CORDLESS WORLD



You need to remove the sticker

BATSTAR
FOR YOUR CORDLESS WORLD



With the help of the screwdriver…



…you remove the sticker



Now open the screw



Disassemble slightly the product, be careful and protect the cable



BATSTAR
FOR YOUR CORDLESS WORLD



Replace broken parts!

BATSTAR
FOR YOUR CORDLESS WORLD

Let‘s rebuild!

BATSTAR
FOR YOUR CORDLESS WORLD



Connect microphone boom and speaker again



Assemble backwards with the help of the screwdriver

BATSTAR
FOR YOUR CORDLESS WORLD



Take the sticker…



…and put it back to its original position

BATSTAR
FOR YOUR CORDLESS WORLD



Carefully combine speaker and headband. CLICK!





Take the mounting disk with ear-pad

BATSTAR
FOR YOUR CORDLESS WORLD



For fixing it on the speaker…

BATSTAR
FOR YOUR CORDLESS WORLD



BATSTAR
FOR YOUR CORDLESS WORLD

DONE!



with rebuilding the Overhead Comfort-Headset